

=1G.2

ERROR CHECKING CODE
CHANNEL USE PERIOD
SENDER ADDRESS
DESTINATION ADDRESS
PACKET TYPE (RTR)

RTR


-1<u>G</u>.3


ERROR CHECKING CODE CHANNEL USE PERIOD SENDER ADDRESS DESTINATION ADDRESS PACKET TYPE (RTS)


RTS

-<u>1</u>G.4

ERROR CHECKING CODE	
CHANNEL USE PERIOD	
DESTINATION ADDRESS	
PACKET TYPE (CTS)	
CTS	














FIG.8











13/13

FIG.13

